

C€ BUWAL

2 Nox

RL BLU SERIES

▶ RL 22 BLU 130 + 249 kW ▶ RL 32 BLU 237 + 356 kW



RL BLU

2가

802,000 kcal/hr

1 /2 2

356,000 kcal/hr


3


STATU PANNEL



Model			▼ RL22 BLU	▼ RL32 BLU	
Cattlena	Funa				
Setting type			Two-stage		
Modulation ratio at max. output		k. output	1,3+1		
Serve- motor	Type Run time		STA4,5 B0.37/6		
	Run time	*	4,5 95/130+249 166/237+356		
Heat output		kW	9.75.00.00.00.00.00.00.00.00.00.00.00.00.00	166/237-356	
		Mcal/h	82/112+214	143/204-306	
		Kg/h	8/11+21	14/20+30	
Workin	g temperature	°C min./max.	0/40		
Net calorific value		kWh/kg	11,8		
	Koal/kg		10200		
Viscosit	ty at 20°C	mm²/s (cSt)	4+6		
Pump	Туре		AT 2 56 C		
	Output	kg/h a 20 bar	60		
Atomised pressure		ber	20		
Fuel temperature		Max. °C	50		
Fan		Туре	Centrifugal with reverse curve blades		
1000000	perature	Max. °C	60		
	al supply	Ph/Hz/V	1/50/230-(±10%)		
	electrical supply	Ph/Hz/V	1/50/230-(:10%)		
Control		Туре	LOA 24		
	ectrical power	kW	0,6	0,6	
Protection level		kW	0,18	0,18	
		IP		44	
Motor electrical power		kW	0,42	0,42	
	notor current	A	2,9	2,9	
	start current	A	11	11	
	protection level	IP	54		
ignition		V1 - V2	230V - 2x5 kV 1,9A - 30 mA		
transfor	STATE OF THE REAL PROPERTY.	H - I2			
Operation			Intermittent (at least one stop every 24 h)		
Sound	pressure	dBA	71	72	
		w	-	-	
CO emi	70.00	mg/kWh	< 10		
Grade of	smoke indicator	Nº Bach.	d		
C _x H _y En		mg/kWh	10 (After the first 20 s)		
NOx Emission		mg/kWh	< 120		
According to Certification			73/23 - 89/336 - 98/37 - 92/42 EEC		
			EN 267 - LRV 92		
			BUWAL Nr 100009		

Reference conditions: Temperature: 20°c Pressure: 1013.5 mbar Attitude: 100 meters a.S.L. Noise measured at a distance of 1 meter.






Useful rate for the choice of the burner


1 1 stage operating rate

Test conditions conforming to EN 267: Temperature: 20°C Pressure: 1013.5 mbar Altitude: 100 m.s.l.










NO CO


EN267

NO₂ 2.116

ppm



Combustion head operating diagram



RL /BLU conical()

. 2 가

가

